

Update procedure for DayClock 10 (TM1010) - EN



(sub-instructions are not always shown)

Note, sometimes you may have to swipe the screen up or down to find an option.

1. Use the 3-finger option to select the DayClock "Settings" menu.
2. Make sure your WiFi is active on the DayClock.
3. Now, from this DayClock "Settings" menu, swipe down the screen and select the "gear".
4. Select "Apps"
5. Select the currently visible gear wheel at the top right.
6. Select "Home screen app"
7. Select "Launcher3"
8. Press 2x on the triangle ◀ on the bottom menu line.
9. Swipe up and select "Security"
10. Swipe up again and select "Unknown sources"
11. Press "OK" (ball goes to the right)
12. Press the circle ⊙ on the bottom menu line.
13. Select "Chrome"... and if necessary "accept, continue, no thanks"
14. Type the web address on the top menu line: <https://bit.ly/dayclockduo>
15. Select "enter" (arrow right on your keyboard)
16. Type the web address on the top menu line: <http://bit.ly/2zdkEFB>
17. Select "enter" (arrow right on your keyboard)
18. Chrome needs access... choose "Continue, Allow" if necessary
19. Swipe the screen down and select "duo.apk"
20. Select "Install"... the software will be installed.
21. Swipe the screen down and select "tc-agenda-10-update.apk"
22. Select "Install"... the software will be installed.
23. Select "done"
24. Swipe the screen down and select the gear again.
25. Select "Security" again.
26. Now turn off "Unknown Sources"! (bullet goes to the left).
27. Select the triangle ◀ on the bottom menu bar.
28. Swipe the screen down and select "Apps"
29. Select the currently visible gear wheel at the top right.
30. Select "Home screen app"
31. Select "Clock"

32. Press the circle ☉ on the bottom menu line.
33. You now have the latest version
34. Now you must log-out and log-in into the App again to synchronise it with the DayClock.